



Where Automation Connects.



# inRAX<sup>®</sup> MVI56E-MCM / MCMXT

ControlLogix Platform  
Modbus Communication Module

June 28, 2010

SETUP GUIDE

## Important Safety Information - MVI56E and MVI56E-XT Modules

### North America Warnings

- A** Warning - Explosion Hazard - Substitution of components may impair suitability for Class I, Division 2.
- B** Warning - Explosion Hazard - When in Hazardous Locations, turn off power before replacing or rewiring modules.  
Warning - Explosion Hazard - Do not disconnect equipment unless power has been switched off or the area is known to be nonhazardous.
- C** Suitable for use in Class I, Division 2 Groups A, B, C, and D, Hazardous Locations or Non-Hazardous Locations.

### ATEX Warnings and Conditions of Safe Usage:

Power, Input, and Output (I/O) wiring must be in accordance with the authority having jurisdiction

- A** Warning - Explosion Hazard - When in hazardous locations, turn off power before replacing or wiring modules.
- B** Warning - Explosion Hazard - Do not disconnect equipment unless power has been switched off or the area is known to be non-hazardous.
- C** These products are intended to be mounted in an IP54 enclosure. The devices shall provide external means to prevent the rated voltage being exceeded by transient disturbances of more than 40%. This device must be used only with ATEX certified backplanes.
- D** DO NOT OPEN WHEN ENERGIZED.

### Ratings

- Backplane Current Load: 800 mA @ 5 Vdc; 3 mA @ 24 Vdc
- Operating Temperature:  
For standard MVI56E modules: 0°C to 60°C (32°F to 140°F);  
For MVI56E XT (conformal coated): -25°C to 70°C (-13°F to 158°F)
- Storage Temperature: -40°C to 85°C (-40°F to 185°F)
- Shock: 30 g operational; 50 g non-operational; Vibration: 5 g from 10 to 150 Hz
- Relative Humidity 5% to 95% (without condensation)
- All phase conductor sizes must be at least 1.3 mm (squared) and all earth ground conductors must be at least 4mm (squared).
- MVI56E XT module comes with conformal coating installed.

### Markings

ANSI / ISA	ISA 12.12.01 Class I Division 2, GPs A, B, C, D
CSA/cUL	C22.2 No. 213-M1987
CSA CB Certified	IEC61010
ATEX	EN60079-0 Category 3, Zone 2 EN60079-15



243333



E183151

RoHS

CL I Div 2 GP A, B, C, D

Temp Code T4

II 3 G

Ex nA nL IIC T4 X

-20°C ≤ Ta ≤ 70°C

II – Equipment intended for above ground use (not for use in mines).

3 – Category 3 equipment, investigated for normal operation only.

G – Equipment protected against explosive gasses.

## **Battery Life Advisory**

The module uses a rechargeable Lithium Vanadium Pentoxide battery to backup the real-time clock and CMOS settings. The battery itself should last for the life of the module. However, if left in an unpowered state for 14 to 21 days, the battery may become fully discharged and require recharging by being placed in a powered-up ControlLogix chassis. The time required to fully recharge the battery may be as long as 24 hours.

Once it is fully charged, the battery provides backup power for the CMOS setup and the real-time clock for approximately 21 days. Before you remove a module from its power source, ensure that the battery within the module is fully charged (the BATT LED on the front of the module goes OFF when the battery is fully charged). If the battery is allowed to become fully discharged, the module will revert to the default BIOS and clock settings.

**Note:** The battery is not user-replaceable or serviceable.

## **ProSoft Technology® Product Documentation**

In an effort to conserve paper, ProSoft Technology no longer includes printed manuals with our product shipments. User Manuals, Datasheets, Sample Ladder Files, and Configuration Files are provided on the enclosed CD-ROM, and are available at no charge from our web site: [www.prosoft-technology.com](http://www.prosoft-technology.com)

Printed documentation is available for purchase. Contact ProSoft Technology for pricing and availability.

North America: +1.661.716.5100

Asia Pacific: +603.7724.2080

Europe, Middle East, Africa: +33 (0) 5.3436.87.20

Latin America: +1.281.298.9109

## **Your Feedback Please**

We always want you to feel that you made the right decision to use our products. If you have suggestions, comments, compliments or complaints about our products, documentation, or support, please write or call us.

### **ProSoft Technology**

5201 Truxtun Ave., 3rd Floor

Bakersfield, CA 93309

+1 (661) 716-5100

+1 (661) 716-5101 (Fax)

[www.prosoft-technology.com](http://www.prosoft-technology.com)

[support@prosoft-technology.com](mailto:support@prosoft-technology.com)

**Copyright © 2010 ProSoft Technology, Inc., all rights reserved.**

MVI56E-MCM / MCMXT Setup Guide

6/23/2010

ProSoft Technology<sup>®</sup>, ProLinx<sup>®</sup>, inRAx<sup>®</sup>, ProTalk<sup>®</sup>, and RadioLinx<sup>®</sup> are Registered Trademarks of ProSoft Technology, Inc. All other brand or product names are or may be trademarks of, and are used to identify products and services of, their respective owners.

# Contents

Important Safety Information - MVI56E and MVI56E-XT Modules .....	2
Battery Life Advisory .....	3
ProSoft Technology® Product Documentation .....	3
Your Feedback Please .....	4
<b>1 Scope</b> .....	<b>7</b>
1.1 What's New? .....	8
1.2 Learning Objectives .....	9
1.3 ProSoft Technology Documentation .....	10
1.4 Prerequisites .....	11
<b>2 Before You Begin</b> .....	<b>13</b>
2.1 System Requirements .....	13
2.2 Required Items .....	14
2.3 Sample Files .....	15
<b>3 Install the Configuration Tools</b> .....	<b>17</b>
3.1 Install ProSoft Discovery Service .....	17
<b>4 The Sample Application</b> .....	<b>19</b>
4.1 About the MODBUS Protocol .....	19
4.2 General Overview .....	20
4.2.1 Required Steps .....	21
4.3 Architecture .....	22
4.4 Memory Map .....	23
<b>5 Procedures</b> .....	<b>25</b>
5.1 Physical Setup .....	25
5.1.1 Set Module Jumpers .....	25
5.1.2 Install the Module in the Rack .....	26
5.1.3 Connect Your PC to the Module's Ethernet Port .....	27
5.1.4 Set Temporary IP Address .....	28
5.1.5 Connect to the Module's Web Page .....	30
5.1.6 Upload the Add-On Instruction from the Module .....	31
5.2 Connect your PC to the ControlLogix Processor .....	39
5.3 Download the Sample Program to the Processor .....	40
5.4 Set up the Read and Write Database Areas .....	41
5.4.1 Configure Modbus Port 1 (P1) .....	42
5.4.2 Configure the Modbus Master Read Command .....	44
5.4.3 Configure the Modbus Master Write Command .....	45
5.5 Reboot the Module to Transfer New Parameter Values .....	46
5.6 Configure the Quantum Processor as a Modbus Slave .....	47
5.7 Connect the MVI56E-MCM Module to the Quantum Processor .....	48

---

5.8	Verify Communication.....	49
5.8.1	View Exchanged Data .....	49
5.8.2	Check Module Status through ControlLogix Controller Tags .....	52
5.8.3	Scrolling LED Status Indicators .....	53
5.8.4	Non-Scrolling LED Status Indicators .....	54
<b>6</b>	<b>Building on Success</b>	<b>55</b>
6.1	Frequently Asked Questions.....	56
6.1.1	What are the differences between the MVI56 and the MVI56E modules? What does the "E" stand for?.....	56
6.1.2	Is the MVI56E product a direct replacement to my existing MVI56 product?.....	57
6.1.3	How is the MVI56E-MCM configured? .....	57
6.1.4	What is ProSoft Configuration Builder (PCB)? .....	57
6.1.5	What is ProSoft Discovery Service (PDS)? .....	57
6.1.6	What is the purpose of the MVI56E-MCM Ethernet Config (E1) Port? .....	57
6.1.7	How do I change the module's IP address? .....	57
6.1.8	Does the MVI56E-MCM module require processor logic? .....	58
6.1.9	What is the purpose of the Optional MVI56E-MCM Add-On Instruction? .....	58
6.1.10	How do I monitor MVI56E-MCM operation?.....	58
6.1.11	Are there any other ways to monitor module diagnostics besides being connected to the module's network (subnet)? .....	58
<b>7</b>	<b>Glossary of Terms</b>	<b>59</b>
<b>Index</b>		<b>63</b>

---

# 1 Scope

## *In This Chapter*

❖ What's New? .....	8
❖ Learning Objectives.....	9
❖ ProSoft Technology Documentation.....	10
❖ Prerequisites .....	11

This document acts as a tutorial, providing step-by-step instructions on how to read and write bi-directional data from one network device to another network device using the MVI56E-MCM / MCMXT.

## 1.1 What's New?

MVI56E products are **backward compatible** with existing MVI56 products, ladder logic, and module configuration files already in use. Easily swap and upgrade to benefit from an array of new features designed to improve interoperability and enhance ease of use.

- **Web Server:** The built-in web server and web page allow access to manuals and other tools previously provided only on a product CD-ROM or from the ProSoft Technology® web site.
- **ProSoft Configuration Builder (PCB):** Microsoft Windows®-based utility software for diagnostics. Connect through the module's Ethernet port or use CIPconnect® to access troubleshooting features and functions.
- **ProSoft Discovery Service (PDS):** New Windows-based utility software to find and display a list of MVI56E modules on the network and to temporarily change a module's IP address to be able to connect with a module's web page.
- **CIPconnect-enabled:** Allows PC-to-module diagnostics from the Ethernet network through a ControlLogix® 1756-ENxT EtherNet/IP™ module.
- **Personality Card:** An industrial-grade compact flash memory card storing the module's Ethernet settings, allowing quick and easy replacement.
- **LED Scrolling Diagnostic Display:** 4-character, alphanumeric display, providing English messages for status and alarm data, and for processor and network communication status.
- **XT series for Extreme Environments:** The MVI56E-MCMXT is part of the new XT series, designed to work at extreme temperatures and in harsh or caustic environments. XT series modules operate over a wider temperature range than the standard MVI56E series. The XT series also come with conformal coating to protect module components from corrosive environmental elements.

## 1.2 Learning Objectives

When you have completed all the steps in this Setup Guide, you will have learned how to

- Use the sample application (page 19)
- Install the MVI56E-MCM setup and diagnostic software (page 17)
- Install the MVI56E-MCM module (page 25)
- Import the Add-On Instruction to the processor (page 40)
- Configure the Modbus Master using the sample Add-On Instruction
- Configure the Modbus Slave (page 47)
- Verify the MVI56E-MCM module communication status (page 49)

### 1.3 ProSoft Technology Documentation

ProSoft Technology provides the following documentation (manuals) with your MVI56E-MCM.

**Electronic documentation (on the MVI56E-MCM web page)**

- **Setup Guide: (this manual)** Describes a sample application, and takes you through the steps necessary to install, configure, and verify the correct operation of the module
- **User Manual:** Detailed reference guide to the module, protocol configuration, functional overview, diagnostics and troubleshooting procedures, and product specifications
- **Datasheet:** Brief description of the module hardware and protocol implementation, as well as general and functional specifications

**Additional documentation, tools, and product support**

- **Web Site Support:** Visit the ProSoft Technology web site at [www.prosoft-technology.com](http://www.prosoft-technology.com) to download additional documentation, tools, and application information.
- **Email Technical Support:** Send your support questions to [Support@prosoft-technology.com](mailto:Support@prosoft-technology.com).
- **Telephone Support:** Please call ProSoft Technology Technical Support at: (Country Code 1+) 661-716-5100. Support is available 24 hours a day, 7 days a week. ProSoft Technology telephone support is free and unlimited.

## 1.4 Prerequisites

To get the most benefit from this *Setup Guide*, you should have the following skills:

- **Rockwell Automation® RSLogix™ 5000 software:** launch the program, configure, and transfer the Add-On Instruction (or ladder logic) Sample Application program to the processor
- **Microsoft Windows®:** install and launch programs, execute menu commands, navigate dialog boxes and enter data.
- **Serial data communication:** correctly configure data communication parameters such as baud rate, parity, data bits, and so on, using the documentation for the devices connected to the network
- **Ethernet networking:** connect the MVI56E-MCM module to an Ethernet network using a valid IP address and subnet mask
- **Hardware installation and wiring:** install the module and safely connect Modbus Master/Slave and ControlLogix devices to a power source and to the MVI56E-MCM module's serial ports



## 2 Before You Begin

### *In This Chapter*

❖ System Requirements .....	13
❖ Required Items .....	14
❖ Sample Files.....	15

### 2.1 System Requirements

The MVI56E-MCM module requires the following minimum hardware and software components:

- Rockwell Automation ControlLogix<sup>®</sup> processor (firmware version 10 or higher), with compatible power supply, and one free slot for the MVI56E-MCM module. The module requires 800 mA of available 5 Vdc power
- Rockwell Automation RSLogix 5000 programming software
  - Version 16 or higher required for Add-On Instruction
  - Version 15 or lower must use Sample Ladder, available from [www.prosoft-technology.com](http://www.prosoft-technology.com)
- Rockwell Automation RSLinx<sup>®</sup> communication software version 2.51 or higher
- ProSoft Configuration Builder (PCB) (included)
- ProSoft Discovery Service (PDS) (included in PCB)
- Pentium<sup>®</sup> II 450 MHz minimum. Pentium III 733 MHz (or better) recommended
- Supported operating systems:
  - Microsoft Windows<sup>®</sup> Vista
  - Microsoft Windows XP Professional with Service Pack 1 or 2
  - Microsoft Windows 2000 Professional with Service Pack 1, 2, or 3
  - Microsoft Windows Server 2003
- 128 Mbytes of RAM minimum, 256 Mbytes of RAM recommended
- 100 Mbytes of free hard disk space (or more based on application requirements)
- 256-color VGA graphics adapter, 800 x 600 minimum resolution (True Color 1024 × 768 recommended)
- CD-ROM drive

Note: The Hardware and Operating System requirements in this list are the minimum recommended to install and run software provided by ProSoft Technology<sup>®</sup>. Other third party applications may have different minimum requirements. Refer to the documentation for any third party applications for system requirements.

Note: You can install the module in a local or remote rack. For remote rack installation, the module requires EtherNet/IP or ControlNet communication with the processor.

## 2.2 Required Items

This Setup Guide uses a sample application that shows you how to establish communication between the MVI56E-MCM module (Master Port) and a Modbus Slave device. The sample application requires the following equipment.

<b>Item</b>	<b>Description</b>
MVI56E-MCM	Modbus Communication Module
1756-L63	ControlLogix processor
1756-A7/B	ControlLogix rack
1756-PA72/B	ControlLogix rack power supply
CPU434 12A	Quantum processor (Modbus device)
CPS 114 20	Quantum power supply
140XBP01000	Quantum rack
Ethernet cable	Ethernet cable to connect MVI56E-MCM module to Ethernet network for diagnostics (supplied with the module)
Serial cable	Serial cable to connect MVI56E-MCM module to Modbus serial network

## 2.3 Sample Files

The following file is required for this procedure:

Item	Description
MVI56(E)MCM_AddOn_Rung_v2_2.L5X	Sample rung import file containing Add-On Instruction

This procedure requires RSLogix 5000 version 16 (or later), which supports Add-On Instructions. The sample MVI56(E)MCM\_AddOn\_Rung\_v2\_2.L5X Add-On Instruction file contains all elements required for the MVI56E-MCM module to function.

- User-defined Data Types (UDTs)
- Add-On Instruction (AOI)
- Ladder rung with AOI
- Controller tags

The AOI L5X rung import file is located on the module's built-in web page.

**Note:** For RSLogix v15 (or older) applications, please refer to the *MVI56E-MCM User Manual* for information on how to use the sample ladder logic.



## 3 Install the Configuration Tools

### *In This Chapter*


- ❖ Install ProSoft Discovery Service ..... 17

### 3.1 Install ProSoft Discovery Service

You must install the ProSoft Discovery Service (PDS) software in order to configure the MVI56E-MCM module's temporary IP address. This will allow you to access the module's web page to download product documentation and sample files and to set the module's permanent network address and settings.

#### ***To install ProSoft Discovery Service from the CD-ROM***

- 1 Insert the ProSoft Solutions CD-ROM into the CD drive of your PC. Wait for the startup screen to appear.



- 2 On the startup screen, click **INSTALL PROSOFT DISCOVERY SERVICE**. This action starts the installation wizard.
- 3 Click **NEXT** on each page of the installation wizard. Click **FINISH** on the last page of the wizard.



## 4 The Sample Application

### *In This Chapter*

❖ About the MODBUS Protocol .....	19
❖ General Overview.....	20
❖ Architecture .....	22
❖ Memory Map .....	23

### 4.1 About the MODBUS Protocol

MODBUS is a widely-used protocol originally developed by Modicon in 1978. Since that time, the protocol has been adopted as a standard throughout the automation industry.

The original MODBUS specification uses a serial connection to communicate commands and data between Master and Slave devices on a network. Later enhancements to the protocol allow communication over other types of networks.

MODBUS is a Master/Slave protocol. The Master establishes a connection to the remote Slave. When the connection is established, the Master sends the MODBUS commands to the Slave. The MVI56E-MCM module can work as a Master and as a Slave.


The MVI56E-MCM module also works as an input/output module between itself and the Rockwell Automation backplane and processor. The module uses an internal database to pass data and commands between the processor and Master and Slave devices on MODBUS networks.

## 4.2 General Overview

This Setup Guide shows you how to configure the MVI56E-MCM module and establish communication with a Modbus device (a Quantum processor, for this example).

The MVI56E-MCM Port 1 (P1) will be configured as a Modbus Master device. The Quantum processor will operate as a Modbus Slave device (Modbus Comm 1). The MVI56E-MCM will be configured to send two Master commands to the Modbus Slave device:

- Write 10 words (Modbus Function 16 - Preset [Write] Multiple Registers)
- Read 10 words (Modbus Function 3 - Read Holding Registers)



When you finish the steps in this Setup Guide, you will have enough information to set up your own application.

### **4.2.1 Required Steps**

This Setup Guide will take you through the following steps:


- 1** Install the ProSoft Module in the rack (page 25)
- 2** Use the Add-On Instruction to Configure the Module (page 32)
- 3** Connect your PC to the Processor (page 39)
- 4** Download the Sample Program to the Processor (page 40)
- 5** Set up the Read and Write Database Areas
  - a** Configure Modbus Port 1 (P1) (page 42)
  - b** Configure the Modbus Master Read Command (page 44, page 45)
  - c** Configure the Modbus Master Write Command (page 45)
- 6** Reboot the module (page 46)
- 7** Set up the Quantum Processor Modbus Slave Port (page 47)
- 8** Verify Communication (page 49)

### 4.3 Architecture

The sample application uses the following hardware and connections.

- A Personal Computer running a supported version of Microsoft Windows, with a web browser, RSLogix 5000, ProSoft Discovery Service and an Ethernet port
- A ControlLogix processor with MVI56E-MCM module acting as a Modbus Master
- A Quantum processor acting as a Modbus Slave
- An Ethernet network connecting the PC with the MVI56E-MCM, either directly or through an Ethernet hub or switch.
- An RS-232 serial cable connecting the MVI56E-MCM Modbus Master Port 1 to the Quantum processor Modbus Slave Port.

The following illustration shows the sample application.



Note: The illustration does not show the required Ethernet connection for processor programming.

#### 4.4 Memory Map

The memory map consists of the starting addresses for Read Data and Write Data areas in the MVI56E-MCM module and in the Quantum processor. The sample application reads and writes 10 words between the Modbus Master and the Modbus Slave.

The following table describes the memory map for data transfer between the MVI56E-MCM module and the Quantum processor.

Function	MVI56E-MCM Database Start Address (Master)	Quantum Memory Start Address (Slave)	Word Count
Read	1000	400801	10
Write	0	400401	10



## 5 Procedures

### *In This Chapter*


- ❖ Physical Setup ..... 25
- ❖ Connect your PC to the ControlLogix Processor ..... 39
- ❖ Download the Sample Program to the Processor ..... 40
- ❖ Set up the Read and Write Database Areas ..... 41
- ❖ Reboot the Module to Transfer New Parameter Values ..... 46
- ❖ Configure the Quantum Processor as a Modbus Slave ..... 47
- ❖ Connect the MVI56E-MCM Module to the Quantum Processor ..... 48
- ❖ Verify Communication ..... 49

### 5.1 Physical Setup

#### 5.1.1 Set Module Jumpers

There are three jumpers located at the bottom of the module. The first two jumpers (PRT1 and PRT2) set the serial communication mode: RS-232, RS-422, or RS-485.

The following illustration shows the MVI56E-MCM jumper configuration.



- 1 The sample application will connect the MVI56E-MCM application port P1 to the target device using the supplied null-modem cable (RS-232). Set the PRT1 jumper for RS-232.
- 2 The Setup Jumper acts as "write protection" for the module's flash memory. In "write protected" mode, the Setup pins are not connected, and the module's firmware cannot be overwritten. The module is shipped with the Setup pins jumpered, so that you can update the module's firmware if necessary. As you will not be updating the firmware for this procedure, remove the setup jumper and store it in a safe place (for example, on only one of the pins).

Note: If you are installing the module in a remote rack, you may prefer to leave the Setup pins jumpered. That way, you can update the module's firmware without requiring physical access to the module.

### **5.1.2 Install the Module in the Rack**

If you have not already installed and configured your ControlLogix processor and power supply, please do so before installing the MVI56E-MCM module. Refer to your Rockwell Automation product documentation for installation instructions.

**Warning:** You must follow all safety instructions when installing this or any other electronic devices. Failure to follow safety procedures could result in damage to hardware or data, or even serious injury or death to personnel. Refer to the documentation for each device you plan to connect to verify that suitable safety procedures are in place before installing or servicing the device.

After you have checked the placement of the jumpers, insert the MVI56E-MCM into the ControlLogix chassis. Use the same technique recommended by Rockwell Automation to remove and install ControlLogix modules.


You can install or remove ControlLogix system components while chassis power is applied and the system is operating. However, please note the following warning.

**Warning:** When you insert or remove the module while backplane power is on, an electrical arc can occur. An electrical arc can cause personal injury or property damage by:

- sending an erroneous signal to your system's actuators causing unintended machine motion or loss of process control
- causing an explosion in a hazardous environment

Verify that power is removed or the area is non-hazardous before proceeding. Repeated electrical arcing causes excessive wear to contacts on both the module and its mating connector. Worn contacts may create electrical resistance that can affect module operation.

- 3 Align the module with the top and bottom guides, and then slide it into the rack until the module is firmly against the backplane connector.




- 4 With a firm, steady push, snap the module into place.
- 5 Check that the holding clips on the top and bottom of the module are securely in the locking holes of the rack.
- 6 Make a note of the slot location. You must identify the slot in which the module is installed in order for the sample program to work correctly. Slot numbers are identified on the green circuit board (backplane) of the ControlLogix rack.
- 7 Turn power ON.

Note: If you insert the module improperly, the system may stop working, or may behave unpredictably.

Note: When using the MVI56EMCMXT, you must use the 1756-A5XT or 1756-A7LXT chassis.

### 5.1.3 Connect Your PC to the Module's Ethernet Port

With the module securely mounted, connect one end of the Ethernet cable to the **CONFIG (E1)** Port, and the other end to an Ethernet hub or switch accessible from the same network as your PC. Or, you can connect directly from the Ethernet Port on your PC to the **CONFIG (E1)** Port on the module.




### 5.1.4 Set Temporary IP Address


**Important:** ProSoft Discovery Service locates MVI56E modules through UDP broadcast messages. These messages may be blocked by routers or layer 3 switches. In that case, ProSoft Discovery Service will be unable to locate the modules.

To use ProSoft Discovery Service, arrange the Ethernet connection so that there is no router or layer 3 switch between the computer and the module OR reconfigure the router or layer 3 switch to allow routing of UDP broadcast messages.


- 1 Click the **START** button, and then navigate to **PROGRAMS / PROSOFT TECHNOLOGY**



- 2 Click to start **PROSOFT DISCOVERY SERVICE**



- 3 Select the module to configure, and right-click to open a shortcut menu.




- 4 On the shortcut menu, choose **ASSIGN TEMPORARY IP**. The module's default IP address is 192.168.0.250.




- 5 Enter an unused IP address within your subnet and your Network Mask, and then click **OK**.

### 5.1.5 Connect to the Module's Web Page

- 1 In *ProSoft Discovery Service*, select the module to configure, and then click the right mouse button to open a shortcut menu.
- 2 On the shortcut menu, choose **VIEW MODULE'S WEBPAGE**.



The web page contains the product documentation and sample programs.




**Important:** The temporary IP address is only valid until the next time the module is initialized. Please refer to the *MVI56E-MCM User Manual* for information on how to set the module's permanent IP address.

You will need the User Manual and the Add-On Software to complete the steps in the following sections of this Setup Guide.

### 5.1.6 Upload the Add-On Instruction from the Module

Configuration and control information for the MVI56E-MCM module is provided as an Add-On Instruction for RSLogix 5000, version 16 or higher.




Two Add-On Instructions are provided:


- The **RUNG IMPORT WITH SAMPLE PROGRAM ADD-ON INSTRUCTION**:  
MVI56(E)MCM\_AddOn\_Rung\_v2\_2.L5X  
Includes the User Defined Data Types, data objects and ladder logic required to configure the MVI56E-MCM module.
- The **RUNG IMPORT WITH UTILITY ADD-ON INSTRUCTION (OPTIONAL)**:  
MVI56(E)MCM\_Optional\_AddOn\_Rung\_v1\_0.L5X  
Includes the data types and controller tags that allow you to update the IP address, date and time on the module.

Create a new RSLogix 5000 project

- 1 Open the **FILE** menu, and then choose **NEW...**



- 2 Select your ControlLogix controller model.
- 3 Select **REVISION 16**.
- 4 Enter a name for your controller, such as "My\_Controller".
- 5 Select your ControlLogix chassis type.
- 6 Select **SLOT 0** for the controller.




Create the Module

- 1 Add the MVI56E-MCM module to the project.


In the **CONTROLLER ORGANIZATION** window, select **I/O CONFIGURATION** and click the right mouse button to open a shortcut menu. On the shortcut menu, choose **NEW MODULE...**



This action opens the **SELECT MODULE** dialog box.



- 2 Select the **1756-MODULE (GENERIC 1756 MODULE)** from the list and click **OK**. This action opens the **NEW MODULE** dialog box.



**3** In the **NEW MODULE** dialog box, enter the following values.


Parameter	Value
<b>NAME</b>	MCM
<b>DESCRIPTION</b>	Enter a description for the module. Example: Modbus Communication Module
<b>COMM FORMAT</b>	Select <b>DATA-INT</b>
<b>SLOT</b>	Enter the slot number in the rack where the MVI56E-MCM module is located
<b>INPUT ASSEMBLY INSTANCE</b>	1
<b>INPUT SIZE</b>	250
<b>OUTPUT ASSEMBLY INSTANCE</b>	2
<b>OUTPUT SIZE</b>	248
<b>CONFIGURATION ASSEMBLY INSTANCE</b>	4
<b>CONFIGURATION SIZE</b>	0

**Important:** You must select the **COMM FORMAT** as **DATA - INT** in the dialog box, otherwise the module will not communicate over the backplane of the ControlLogix rack.

**4** Click **OK** to continue.


**5** Edit the Module Properties.

Select the **REQUESTED PACKET INTERVAL** value for scanning the I/O on the module. This value represents the minimum frequency at which the module will handle scheduled events. This value should not be set to less than 1 millisecond. The default value is 5 milliseconds. Values between 1 and 10 milliseconds should work with most applications.




## 6 Save the module

Click **OK** to close the dialog box. Notice that the module now appears in the **CONTROLLER ORGANIZATION** window.




Import the Ladder Rung


- 1 In the **CONTROLLER ORGANIZATION** window, expand the **TASKS** folder and subfolders until you reach the **MAINPROGRAM** folder.
- 2 In the **MAINPROGRAM** folder, double-click to open the **MAINROUTINE** ladder.
- 3 Select an empty rung in the routine, and then click the right mouse button to open a shortcut menu. On the shortcut menu, choose **IMPORT RUNG...**



- 4 Navigate to the location on your PC where you saved (page 31) the Add-On Instruction (for example, "My Documents" or "Desktop"). Select the **MVI56(E)MCM\_ADDON\_RUNG\_v2\_2.L5X** file




This action opens the **IMPORT CONFIGURATION** dialog box, showing the controller tags that will be created.




- 5 If you are using the module in a different slot (or remote rack), select the correct connection input and output variables that define the path to the module. If your module is located in Slot 1 of the local rack, this step is not required.

- Click **OK** to confirm the import. RSLogix will indicate that the import is in progress:



When the import is completed, the new rung with the Add-On Instruction will be visible as shown in the following illustration.



The procedure has also imported new User Defined Data Types, Controller Tags, and the Add-On instruction for your project.




- Save the application and then download the sample ladder logic into the processor.


## 5.2 Connect your PC to the ControlLogix Processor

There are several ways to establish communication between your PC and the ControlLogix processor. The following steps show how to establish communication through the serial interface. It is not mandatory that you use the processor's serial interface. You may access the processor through whatever network interface is available on your system. Refer to your Rockwell Automation documentation for information on other connection methods.

- 1 Connect the right-angle connector end of the cable to your controller at the communications port.



- 2 Connect the straight connector end of the cable to the serial port on your computer.




### 5.3 Download the Sample Program to the Processor

Note: The key switch on the front of the ControlLogix processor must be in the REM or PROG position.

- 1 If you are not already online with the processor, open the **COMMUNICATIONS** menu, and then choose **DOWNLOAD**. RSLogix will establish communication with the processor. You do not have to download through the processor's serial port, as shown here. You may download through any available network connection.
- 2 When communication is established, RSLogix will open a confirmation dialog box. Click the **DOWNLOAD** button to transfer the sample program to the processor.



- 3 RSLogix will compile the program and transfer it to the processor. This process may take a few minutes.
- 4 When the download is complete, RSLogix will open another confirmation dialog box. If the key switch is in the **REM** position, click **OK** to switch the processor from **PROGRAM** mode to **RUN** mode.



Note: If you receive an error message during these steps, refer to your RSLogix documentation to interpret and correct the error.

### 5.4 Set up the Read and Write Database Areas


The next part of this tutorial is to configure the MVI56E-MCM database read and write areas to define how data will be transferred between the processor and the MVI56E-MCM module.

	Description	Start Register Database Address Parameter	Register Count Database Parameter	Data Controller Tag Array Name
Write Area	Database area transferred from processor to the module	MCM.CONFIG.ModDef. WriteStartReg	MCM.CONFIG.ModDef. WriteRegCnt	MCM.DATA.WriteData
Read Area	Database area transferred from module to the processor	MCM.CONFIG.ModDef. ReadStartReg	MCM.CONFIG.ModDef. ReadRegCnt	MCM.DATA.ReadData

The Write Data and Read Data areas are configured through the following controller tags.

[-] MCM.CONFIG	{...}
[-] MCM.CONFIG.ModDef	{...}
[+] MCM.CONFIG.ModDef.WriteStartReg	0
[+] MCM.CONFIG.ModDef.WriteRegCnt	600
[+] MCM.CONFIG.ModDef.ReadStartReg	1000
[+] MCM.CONFIG.ModDef.ReadRegCnt	600

The settings in the sample application above correspond with the following memory diagram.



### 5.4.1 Configure Modbus Port 1 (P1)

The sample application uses the following configuration settings for Modbus Port 1 (Master) on the MVI56E-MCM module.

Parameter	Value
Modbus Protocol	RTU
Baud Rate	19200
Parity	None
Data Bits	8
Stop Bits	1

The **MODBUS PORT X** configuration parameters are used when the module is configured as a Modbus Master device. Port 1 and Port 2 each have their own set of parameters to configure.

[-] MCM	{ ... }		MCMModuleDef
[-] MCM.CONFIG	{ ... }		MCMCONFIG
[-] MCM.CONFIG.ModDef	{ ... }		MCMModule
[-] MCM.CONFIG.Port1	{ ... }		MCMPort
[-] MCM.CONFIG.Port1.Enabled	1	Decimal	INT
[-] MCM.CONFIG.Port1.Type	0	Decimal	INT
[-] MCM.CONFIG.Port1.FloatFlag	0	Decimal	INT
[-] MCM.CONFIG.Port1.FloatStart	0	Decimal	INT
[-] MCM.CONFIG.Port1.FloatOffset	0	Decimal	INT
[-] MCM.CONFIG.Port1.Protocol	0	Decimal	INT
[-] MCM.CONFIG.Port1.Baudrate	19200	Decimal	INT
[-] MCM.CONFIG.Port1.Parity	0	Decimal	INT
[-] MCM.CONFIG.Port1.DataBits	8	Decimal	INT
[-] MCM.CONFIG.Port1.StopBits	1	Decimal	INT
[-] MCM.CONFIG.Port1.RTSOn	0	Decimal	INT
[-] MCM.CONFIG.Port1.RTSOff	0	Decimal	INT
[-] MCM.CONFIG.Port1.MinResp	0	Decimal	INT
[-] MCM.CONFIG.Port1.UseCTS	0	Decimal	INT
[-] MCM.CONFIG.Port1.SlaveID	0	Decimal	INT
[-] MCM.CONFIG.Port1.BitInOffset	0	Decimal	INT
[-] MCM.CONFIG.Port1.WordInOffset	0	Decimal	INT
[-] MCM.CONFIG.Port1.OutOffset	0	Decimal	INT
[-] MCM.CONFIG.Port1.HoldOffset	0	Decimal	INT
[-] MCM.CONFIG.Port1.CmdCount	100	Decimal	INT
[-] MCM.CONFIG.Port1.MinCmdDelay	0	Decimal	INT
[-] MCM.CONFIG.Port1.CmdErrPtr	1500	Decimal	INT
[-] MCM.CONFIG.Port1.RespTO	1000	Decimal	INT
[-] MCM.CONFIG.Port1.RetryCount	2	Decimal	INT
[-] MCM.CONFIG.Port1.ErrorDelayCntr	0	Decimal	INT
[-] MCM.CONFIG.Port1.Reserved	0	Decimal	INT
[-] MCM.CONFIG.Port1.InterCharacterDelay	0	Decimal	INT
[-] MCM.CONFIG.Port1.Fcn990Offset	0	Decimal	INT

In RSLogix 5000, expand the **MCM.CONFIG.MODDEF** controller tag, and navigate to **MCM.CONFIG.PORT1**.

Any parameters not mentioned in this section are not used or not essential when the module is configured as a Modbus Master.

The following table describes the relevant parameters in the **MCM.CONFIG.MODDEF.PORT1** tag array.

Parameter	Description
Enabled	1 = ENABLE PORT, 0 = disable port
Type	0=MASTER, 1=Slave, 2=Slave: pass-through, 3=Slave: formatted pass-through/data swapped, 4=Slave: form. Pass-through
Protocol	0 = Modbus RTU mode, 1 = Modbus ASCII mode
Baudrate	Sets the baud rate for the port. Valid values for this field are 110, 150, 300, 600, 1200, 4800, 9600, 19200, 384 or 3840 (for 38,400 baud), 576 or 5760 (for 57,600 baud) and 115,1152, or 11520 (for 115,200 baud)
Parity	0 = None, 1 = Odd, 2 = Even
DataBits	Modbus RTU mode = 8 Modbus ASCII mode = 8 or 7
StopBits	Valid values are 1 or 2.
UseCts	No or Yes This parameter is used to enable or disable hardware handshaking. The default setting is <i>No</i> hardware handshaking, CTS Line not used. Set to <i>No</i> if the connected devices do not need hardware handshaking. Set to <i>Yes</i> if the devices connected to the port require hardware handshaking (most modern devices do not) If you set this parameter to <i>Yes</i> , be sure to pay attention to the pinout and wiring requirements to be sure the hardware handshaking signal lines are properly connected; otherwise communication will fail.
RespTO	0 to 65535 milliseconds response timeout for command <b>Note:</b> 1000 = 1000 milliseconds (1 second) before it will either reissue the command, if <b>RETRYCOUNT &gt; 0</b> , or, if the RetryCount =0 or has already been met, then it will move on to the next command in the list.
RetryCount	Number of times to retry a failed request before moving to the next command on the list.
MinCmdDelay	0-65535 milliseconds The amount of delay in milliseconds to be inserted after receiving a slave response or encountering a response timeout before retrying the command or sending the next command on the list. Use this parameter to slow down overall polling speed and spread out commands on networks with slaves that require additional gaps between messages.
CmdErrPtr	Internal DB location to place command error list <b>Note:</b> Set Master Command Errors location. Each command will reserve one word for the command error code for that command. See Verify Communication. <b>CMDERRPTR</b> value should be within the range of the <b>READDATA</b> array. See Backplane Configuration.


### 5.4.2 Configure the Modbus Master Read Command

The Modbus Read Command reads 10 words of data from the Quantum processor (Modbus Slave) and transfers it to the MVI56E-MCM module's internal database. The following table describes the relationship between memory addresses in the Modbus Master (MVI56E-MCM) and the Modbus Slave (Quantum processor).

MVI56E-MCM Database Address	Quantum Memory Address
1000	400801
1001	400802
1002	400803
1003	400804
1004	400805
1005	400806
1006	400807
1007	400808
1008	400809
1009	400810

In the sample program, the Modbus Read Command is present, but disabled. To enable the command, change the 0 (zero) to 1 (one) in the **MCM.CONFIG.PORT1MASTERCMD[0].ENABLE** tag.

Be sure the tag **MCM.CONFIG.PORT1MASTERCMD[0].DEVADDRESS**, is set to 800, as shown in the following illustration.



#### Notes:

- Func 3 represents Modbus Function Code 3, the command code to Read Holding Registers
- The DevAddress parameter is 0-based so 800 = 400801, 801 = 400802, and so on.
- The Enable code must be set to 1 to enable the command (0 = disable)
- The destination Slave node address must be set as 1 (Node parameter)

### 5.4.3 Configure the Modbus Master Write Command

The Modbus Write Command will write data from the MVI56E-MCM module to the Quantum processor as follows.

MVI56E-MCM Database Address	Quantum Memory Address
0	400401
1	400402
2	400403
3	400404
4	400405
5	400406
6	400407
7	400408
8	400409
9	400411

In the sample program, a Modbus Write Command is present, but disabled. To enable this command, change the 0 (zero) to 1 (one) in the **MCM.CONFIG.PORT1MASTERCMD[1].ENABLE** tag.

Be sure the tag, **MCM.CONFIG.PORT1MASTERCMD[1].NODE**, is set to 400 as shown in the following illustration.

MCM.CONFIG.Port1MasterCmd[1] { ... }	
MCM.CONFIG.Port1MasterCmd[1].Enable	0
MCM.CONFIG.Port1MasterCmd[1].IntAddress	0
MCM.CONFIG.Port1MasterCmd[1].PollInt	0
MCM.CONFIG.Port1MasterCmd[1].Count	10
MCM.CONFIG.Port1MasterCmd[1].Swap	0
MCM.CONFIG.Port1MasterCmd[1].Node	1
MCM.CONFIG.Port1MasterCmd[1].Func	16
MCM.CONFIG.Port1MasterCmd[1].DevAddress	100

**Notes:**

- FUNC 16 represents Modbus Function Code 16, the command code to Preset (Write) Holding Registers
- The DEVADDRESS parameter is 0-based so 400 = 400401, 401 = 400402, and so on.
- The ENABLE code must be set to 1 to enable the command (0 = disable).
- The destination Slave node address must be set as 1 (NODE parameter)


## 5.5 Reboot the Module to Transfer New Parameter Values

The changes you made in the sample program do not take effect until you reboot the module.

- 1 Locate the **MCM.CONTROL.WARMBOOT** controller tag.



- 2 Enter a value of 1 into this controller tag.



- 3 Verify that the tag value is automatically reset to zero (0) after a short delay.



The module is now configured with the new parameters, and will begin exchanging data with the processor.

## 5.6 Configure the Quantum Processor as a Modbus Slave

The next part of this tutorial is to configure the remote Modbus Slave. For this example, the Modbus Slave will be a Quantum processor.

The communication port settings for the Modbus Slave must match the Port 1 settings for the Modbus Master. Use the values in the following table to configure the Quantum processor with Schneider Electric's Concept programming software (version 2.6 or higher).

Parameter	Value
Node Address	1
Modbus Protocol	RTU
Baud Rate	19200
Parity	None
Data Bits	8
Stop Bits	1


The following illustration shows the **MODBUS PORT SETTINGS** dialog box in Concept version 2.6.



### 5.7 Connect the MVI56E-MCM Module to the Quantum Processor

The final part of this tutorial is to connect the supplied RJ45 to DB9 adaptor and the supplied null modem cable to Port 1 on the MVI56E-MCM module, and Modbus Comm1 on the Quantum processor.

The following illustration shows the serial connection between the MVI56E-MCM module and the Quantum processor.




## 5.8 Verify Communication

There are several ways to verify that the MVI56E-MCM module is communicating with the processor and with the Modbus Master/Slave network. You can:

- View Exchanged Data (page 49)
- View the Module Status in the RSLogix 5000 Controller Tags (page 52)
- View the LED Status Indicators

### 5.8.1 View Exchanged Data

The following illustration describes the source and destination for the data exchanged by the two Modbus Master Commands.



Check Write Data

The following steps show you how to verify that the WriteData Command is working.

- 1 In RSLogix, navigate to the processor controller tags **MCM.DATA.WRITEDATA[0]** through **MCM.DATA.WRITEDATA[9]**.
- 2 For words **[0]** through **[9]**, enter the numbers shown in the following illustration.

- MCM.DATA.WriteData	{...}
+ MCM.DATA.WriteData[0]	1
+ MCM.DATA.WriteData[1]	2
+ MCM.DATA.WriteData[2]	3
+ MCM.DATA.WriteData[3]	4
+ MCM.DATA.WriteData[4]	5
+ MCM.DATA.WriteData[5]	6
+ MCM.DATA.WriteData[6]	7
+ MCM.DATA.WriteData[7]	8
+ MCM.DATA.WriteData[8]	9
+ MCM.DATA.WriteData[9]	10

This action sends the values you entered to the Modbus Master Port on the MVI56E-MCM, and then to the Quantum processor, where you will be able to see the data in Concept.

- 3 In Concept, navigate to the **REFERENCE DATA EDITOR** to monitor the processor memory addresses from 400401 through 400410. The data should match the data you sent from RSLogix 5000.

RDE Template (untitled) - Animation ON				
	Variable Name	Data Type	Address	Value
1				
2			400401	1
3			400402	2
4			400403	3
5			400404	4
6			400405	5
7			400406	6
8			400407	7
9			400408	8
10			400409	9
11			400410	10

Check Read Data

The following steps show you how to verify that the ReadData Command is working.

- 1 In Concept, navigate to the **REFERENCE DATA EDITOR**, and enter the following values in processor memory addresses from 400801 through 400810 as shown in the following illustration.

RDE Template (untitled) - Animation ON				
	Variable Name	Data Type	Address	Value
14				
15			400801	101
16			400802	102
17			400803	103
18			400804	104
19			400805	105
20			400806	106
21			400807	107
22			400808	108
23			400809	109
24			400810	110

This action populates the memory addresses in the Quantum processor that the MVI56E-MCM will attempt to retrieve with the ReadData Command.

- 2 In RSLogix 5000, the values in **MCM.DATA.READDATA[0]** through **[9]** should match the data you entered in Concept.

[-] MCM.DATA.ReadData	{...}
[+] MCM.DATA.ReadData[0]	101
[+] MCM.DATA.ReadData[1]	102
[+] MCM.DATA.ReadData[2]	103
[+] MCM.DATA.ReadData[3]	104
[+] MCM.DATA.ReadData[4]	105
[+] MCM.DATA.ReadData[5]	106
[+] MCM.DATA.ReadData[6]	107
[+] MCM.DATA.ReadData[7]	108
[+] MCM.DATA.ReadData[8]	109
[+] MCM.DATA.ReadData[9]	110

**Tip:** Repeat these tests, using different values each time, to verify that the same data appears in the proper place in each processor.

### 5.8.2 Check Module Status through ControlLogix Controller Tags

You can view network status through the ControlLogix controller tags that are updated through the MVI56E-MCM sample ladder.

- To verify that the Modbus Master is communicating with one or more Modbus Slaves, view the contents of the two ReadData array elements beginning at the address you used for **MCM.CONFIG.PORTX.CMDERRPTR** parameter, minus the value of the **MCM.CONFIG.MODDEF.READSTARTREG** tag. In this case, the CmdErrPtr was set to 1500 and the ReadStartReg to 1000. This means that (1500 – 1000 = 500); so **READDATA[500]** and **READDATA[501]** will tell you the individual status of each of the two commands issued by the module.
- To verify that the Modbus Slave is communicating with a Modbus Master, view the contents of the **MCM.STATUS.PRTXERRS** tag for total commands issued, responses received, errors, and so on.

- MCM.STATUS.Prt1Errs	{...}
+ MCM.STATUS.Prt1Errs.CmdReq	611
+ MCM.STATUS.Prt1Errs.CmdResp	610
+ MCM.STATUS.Prt1Errs.CmdErr	0
+ MCM.STATUS.Prt1Errs.Requests	611
+ MCM.STATUS.Prt1Errs.Responses	610
+ MCM.STATUS.Prt1Errs.ErrSent	0
+ MCM.STATUS.Prt1Errs.ErrRec	0

The following controller tags should continuously increment indicating that Port 1 is continuously sending commands and receiving responses:

- **MCM.STATUS.PRT1ERRS.CMDREQ**
- **MCM.STATUS.PRT1ERRS.CMDRESP**
- **MCM.STATUS.PRT1ERRS.REQUESTS**
- **MCM.STATUS.PRT1ERRS.RESPONSES**

If the error counters continuously increment, the **LASTERROR** controller tag value shows the command index which caused the latest failure. You can refer to the command error pointer feature to read the command error codes as previously discussed.

+ MCM.STATUS.Port1LastErr	0
+ MCM.STATUS.Port1PreviousErr	0
+ MCM.STATUS.Port2LastErr	0
+ MCM.STATUS.Port2PreviousErr	0

### 5.8.3 Scrolling LED Status Indicators

The scrolling LED display indicates the module's operating status as follows:

#### Initialization Messages

Code	Message
Boot / DDOK	Module is initializing
Ladd	Module is waiting for required module configuration data from ladder logic to configure the Modbus ports
Waiting for Processor Connection	Module did not connect to processor during initialization <ul style="list-style-type: none"> <li>▪ Sample ladder logic or AOI is not loaded on processor</li> <li>▪ Module is located in a different slot than the one configured in the ladder logic/AOI</li> <li>▪ Processor is not in RUN or REM RUN mode</li> </ul>
Last config: <date>	Indicates the last date when the module changed its IP address. You can update the module date and time through the module's web page, or with the MVI56E Optional Add-On Instruction.
Config P1/P2 <Modbus mode> <Port type> <Baud> <Parity> <Data bits> <Stop Bits> <RS Interface> <ID (Slave)> <Cmds: (Master)>	After power up and every reconfiguration, the module will display the configuration of both ports. The information consists of: <ul style="list-style-type: none"> <li>▪ Modbus mode: RTU/ASCII</li> <li>▪ Port type: Master/Slave</li> <li>▪ Baud: 115200 / 57600 / 38400 / 19200 / 9600 / 4800 / 2400 / 1200 / 600 / 300</li> <li>▪ Parity: None / Even / Odd</li> <li>▪ Data bits: 7 / 8</li> <li>▪ Stop bits: 1 / 2</li> <li>▪ RS Interface: RS-232 / RS-422 / RS-485</li> <li>▪ ID: Slave Modbus Address</li> <li>▪ Cmds: Configured Modbus Master Commands</li> </ul>

#### Operation Messages

After the initialization step, the following message pattern will be repeated.

<Backplane Status> <IP Address> <Backplane Status> <Port Status>

Code	Message
<Backplane Status>	OK: Module is communicating with processor ERR: Module is unable to communicate with processor. For this scenario, the <Port Status> message above is replaced with "Processor faulted or is in program mode".
<IP Address>	Module IP address
<Port Status>	OK: Port is communicating without error Master/Slave Communication Errors: port is having communication errors. Refer to PCB diagnostics for further information about the error.

### 5.8.4 Non-Scrolling LED Status Indicators

The non-scrolling LEDs indicate the module’s operating status as follows:

LED Label	Color	Status	Indication
APP	Red or Green	OFF	The module is not receiving adequate power or is not securely plugged into the rack. May also be OFF during configuration download.
		GREEN	The MVI56E-MCM is working normally.
		RED	The most common cause is that the module has detected a communication error during operation of an application port. The following conditions may also cause a RED LED: <ul style="list-style-type: none"> <li>▪ The firmware is initializing during startup</li> <li>▪ The firmware detects an on-board hardware problem during startup</li> <li>▪ Failure of application port hardware during startup</li> <li>▪ The module is shutting down</li> <li>▪ The module is rebooting due to a ColdBoot or WarmBoot request from the ladder logic or Debug Menu</li> </ul>
OK	Red or Green	OFF	The module is not receiving adequate power or is not securely plugged into the rack.
		GREEN	The module is operating normally.
		RED	The module has detected an internal error or is being initialized. If the LED remains RED for over 10 seconds, the module is not working. Remove it from the rack and re-insert it to restart its internal program.
ERR	Red	OFF	The battery voltage is OK and functioning.
		ON	The battery voltage is low or battery is not present. Allow battery to charge by keeping module plugged into rack for 24 hours. If ERR LED still does not go off, contact ProSoft Technology, as the battery is not a user-serviceable item.

## 6 Building on Success

### *In This Chapter*

- ❖ Frequently Asked Questions ..... 56

Now that you have successfully installed, configured, and verified operation of the MVI56E-MCM module, you should have a better understanding of how to make it work for your specific application. The following resources are available to help you build on your success.

- For more information about the MVI56E-MCM module, including detailed hardware and software configuration, troubleshooting, and application information, refer to the *MVI56E-MCM User Manual*.
- For technical support and warranty information for your MVI56E-MCM module, refer to *Support, Service, and Warranty* in the *MVI56E-MCM User Manual*.
- For more information on ProSoft Technology products and services, please visit [www.prosoft-technology.com](http://www.prosoft-technology.com).

## 6.1 Frequently Asked Questions

### 6.1.1 What are the differences between the MVI56 and the MVI56E modules? What does the "E" stand for?

The "E" stands for *Enhanced with Ethernet* communication capabilities. The new enhancements are:

- **PCB:** MVI56E-MCM products now use PCB (ProSoft Configuration Builder) software; a Windows-based configuration utility providing a new graphic user interface for module diagnostics with screen navigation, improving interoperability with the module.
- **Seamless Migration:** MVI56E products are backward compatible with existing ladder logic and module configuration files, allowing for a smooth "plug and play" transition when replacing the earlier version MVI56-MCM product.
- **Personality Memory Module:** The module incorporates a non-volatile Compact Flash (CF) memory card for storing the module's network configuration data (or personality). This feature benefits the end-user with quick replacement of faulted modules and restoration of systems by a simple exchange of the Personality Memory Module with absolutely no PC or configuration requirements.
- **Ethernet Configuration Port:** Allows for remote module connectivity. Replaces serial communication and becomes the primary configuration port, as well as providing a web server interface.
- **Web server:** Provides HTML information about the status of the product and download access to documents and software such as the product manual and configuration software. Components are stored locally in the module's on-board flash memory.
- **LED Display:** The 4-character, scrolling, alphanumeric LED display provides additional detailed plain English diagnostic and error information, backplane communication, and network conditions for the module, .
- **Discovery Service:** Allows PCB configuration software (or separate utility) to find and display products located on the network using key product attributes such as name, serial number, and IP address. The user will be able to change IP address, upload/download, and enter into diagnostics from the list.
- **CIPconnect<sup>®</sup> enabled:** Allows end-users to connect from remote locations to local- and remote-chassis-installed MVI56E modules from anywhere on a Rockwell Automation<sup>®</sup> EtherNet/IP<sup>™</sup> or ControlNet<sup>™</sup> process network, up to six remote links away.

### **6.1.2 Is the MVI56E product a direct replacement to my existing MVI56 product?**

Yes

### **6.1.3 How is the MVI56E-MCM configured?**

The module is configured with ladder logic controller tags. A warm boot operation is required to transfer all parameters from the processor to the module.

### **6.1.4 What is ProSoft Configuration Builder (PCB)?**

ProSoft Configuration Builder (PCB) provides a quick and easy way to manage module diagnostics and troubleshooting operations. Built-in module diagnostics menus and the serial port data stream analyzer can be accessed using PCB through the module's high-speed Ethernet configuration port (E1) or through Rockwell Automation 1756-ENxT or 1756-CNBx communications interfaces using CIPconnect<sup>®</sup>.

### **6.1.5 What is ProSoft Discovery Service (PDS)?**

ProSoft Discovery Service (PDS) is Windows-based software that connects to the Ethernet port of the module for the following purposes:

- Automatic module discovery on the Ethernet network
- Set a temporary IP address for the module for easy commissioning
- Allow PCB to select the module for monitoring and IP address reconfiguration

The ProSoft Discovery Service software is supplied as a stand-alone utility, as well as being integrated into PCB.

### **6.1.6 What is the purpose of the MVI56E-MCM Ethernet Config (E1) Port?**

The MVI56E-MCM Ethernet Port (E1) allows a remote PC to set the module's IP address, as well as monitor module operation using ProSoft Configuration Builder (PCB) diagnostics.

You can also set the IP address with ladder logic. Refer to the *MVI56E-MCM User Manual* for more information on this option.

### **6.1.7 How do I change the module's IP address?**

- 1 Use ProSoft Configuration Builder to edit and download the Ethernet configuration to the module.
- 2 Use the Optional Add-On Instruction (AOI) provided with the module. The AOI can be downloaded from the module's web page.

### **6.1.8 Does the MVI56E-MCM module require processor logic?**

Yes, ladder logic is required for data transfer between the MVI56E module and the ControlLogix<sup>®</sup> processor.

- For RSLogix<sup>™</sup> 5000 version 16 applications (or later), the included Add-On Instruction encapsulates the entire ladder logic into one single instruction.
- For RSLogix 5000 version 15 and older, sample ladder logic is available from the ProSoft Technology<sup>®</sup> website at [www.prosoft-technology.com](http://www.prosoft-technology.com).

### **6.1.9 What is the purpose of the Optional MVI56E-MCM Add-On Instruction?**

The Optional Add-On Instruction (AOI) allows the processor to perform the following tasks:

- 1 Set the MVI56E Ethernet settings
- 2 Read the MVI56E Ethernet settings
- 3 Set MVI56E date/time information
- 4 Read the MVI56E date/time information

Items 1 and 2 can also be performed through ProSoft Configuration Builder (PCB) using ProSoft Discovery Service. Items 3 and 4 can also be performed through the module's built-in web page.

The Optional AOI is needed only for specific applications where Ethernet or CIPconnect access from a programmer's personal computer (PC) to the module is not possible.

### **6.1.10 How do I monitor MVI56E-MCM operation?**

Module operation can be monitored either through the processor controller tags or through the ProSoft Configuration Builder diagnostic window. Available status information includes number of messages sent, number of messages received, number of errors, and error codes.

### **6.1.11 Are there any other ways to monitor module diagnostics besides being connected to the module's network (subnet)?**

PCB can monitor the module via ControlLogix backplanes and process networks using CIPconnect. The PC running PCB can use its Ethernet port to connect to any 1756-ENxT EtherNet/IP<sup>™</sup> interface module which is on the same Ethernet subnet. Through this connection, PCB can use CIPconnect to route through the ControlLogix backplane to other 1756-ENxT or 1756-CNBx modules, for up to five more route links, to reach an MVI56E module in a chassis connected on EtherNet/IP or ControlNet<sup>™</sup> process networks.

## 7 Glossary of Terms

### A

#### ASCII

American Standard Code for Information Interchange. A communication mode in which each eight-bit byte in a message contains one ASCII character code. ASCII characters (or hexadecimal characters) are sometimes used as a key to encrypt data and ensure its secure transmission.

### B

#### Baud Rate

The speed of communication between devices on the network. All devices must communicate at the same rate.

### C

#### Client

A client is a software program, or the device on which that program runs, that makes requests for information from a software program, or the device on which that program runs, in a client-server relationship.

A Client on an Ethernet network is equivalent to a Master on a serial network.

### D

#### DCE

Data communications equipment. A modem, for example.

#### Default Gateway

The IP address of a network router where data is sent if the destination IP address is outside the local subnet. The gateway is the device that routes the traffic from the local area network to other networks such as the Internet.

#### DTE

Data terminal equipment. A computer or terminal, for example.

### E

#### ESD

Electrostatic Discharge. Can cause internal circuit damage to the coprocessor.

### Ethernet

A set of network cabling and network access (CSMA/CD) protocol standards for bus topology computer networks invented by Xerox but now controlled by the 802.3 subcommittee of the IEEE.

## F

### Firmware

Software for embedded computers.

### Full-Duplex

A communications circuit or system designed to simultaneously transmit and receive two different streams of data. Telephones are an example of a full-duplex communication system. Both parties on a telephone conversation can talk and listen at the same time. If both talk at the same time, their two signals are not corrupted.

## H

### Half-Duplex

A communications circuit or system designed to transmit and receive data, but not both simultaneously. CB or walkie-talkie radios are an example of a half-duplex communication system. Either parties on a radio conversation may talk or listen; but both cannot talk at the same time without corrupting each other's signal. If one operator is "talking", the other must be "listening" to have successful communication.

## I

### IP Address

A 32-bit identification number for each node on an Internet Protocol network. These addresses are represented as four sets of 8-bit numbers (numbers from 0 to 255), separated by periods ("dots").

Networks using the TCP/IP Protocol route messages based on the IP address of the destination. Each number can be 0 to 255. For example, 192.168.0.100 could be an IP address. Each node on the network must have a unique IP address.

## L

### LED

Light-emitting diode.

## M

### MAC ID

A hexadecimal number that uniquely identifies an Ethernet device.

### Master

A Master is a device that makes requests for information from a software program, or the device on which that program runs, in a Master-Slave relationship.

A Client on an Ethernet network is equivalent to a Master on a Serial network.

## N

### Network

A series of stations or nodes connected by some type of communication medium. A network may consist of a single link or multiple links.

### Node

An address or software location on the network.

## P

### Peer-to-Peer

A network relationship between devices where each device can send commands as a master or client, and respond to commands as a slave or server.

### Power Supply

Device that supplies electrical power to the I/O chassis containing the processor, coprocessor, or other modules.

### Protocol

The language or packaging of information that is transmitted between nodes on a network.

## R

### RS-232

Recommended Standard 232; the standard for serial binary signals between DTE and DCE devices.

## S

### Serial Data/Serial Data Transmission

Data that is transferred one bit at a time. Serial data transmission involves changing a carrier signal line between two possible states to indicate a binary 0 or binary 1 value. Successive data bits are rapidly transmitted one after the other with a fixed time allowed for each bit. Data bits are usually grouped into "packets", which contain a specific amount of data bits, along with extra bits included to provide error-checking capability.

### Server

A Server is a software program, or the device on which that program runs, that provides a specific kind of service to a Client software program, or the device on which that program runs, on an Ethernet network.

A Server on an Ethernet network is equivalent to a Slave on a Serial network.

### Simplex

A communications circuit or system designed to either transmit data or receive data, but not both. Broadcast television is an example of simplex communication system. A television station sends a TV signal but cannot receive responses back from the television sets to which it is transmitting. The TV sets can receive the signal from the TV station but cannot transmit back to the station.

### Slave

A Slave is a software program, or the device on which that program runs, which provides a specific kind of service to a Master software program, or the device on which that program runs, on a serial network.

A Slave on a Serial network is equivalent to a Server on an Ethernet network.

### Subnet Mask

A mask used to determine what subnet an IP address belongs to. An IP address has two components: the network address, and the host (node or device) address. For example, consider the IP address 150.215.017.009. Assuming this is part of a Class B network (with a subnet mask of 255.255.0.0), the first two numbers (150.215) represent the Class B network address, and the second two numbers (017.009) identify a particular host on this network.

## Index

### A

About the MODBUS Protocol • 19  
Architecture • 22  
Are there any other ways to monitor module  
diagnostics besides being connected to the  
module's network (subnet)? • 58  
ASCII • 59

### B

Battery Life Advisory • 3  
Baud Rate • 59  
Before You Begin • 13  
Building on Success • 55

### C

Check Module Status through ControlLogix Controller  
Tags • 49, 52  
Check Read Data • 51  
Check Write Data • 50  
Client • 59  
Configure Modbus Port 1 (P1) • 21, 42  
Configure the Modbus Master Read Command • 21,  
44  
Configure the Modbus Master Write Command • 21, 45  
Configure the Quantum Processor as a Modbus Slave  
• 9, 21, 47  
Connect the MVI56E-MCM Module to the Quantum  
Processor • 48  
Connect to the Module's Web Page • 30  
Connect your PC to the ControlLogix Processor • 21,  
39  
Connect Your PC to the Module's Ethernet Port • 27  
Create a new RSLogix 5000 project • 21, 32  
Create the Module • 33

### D

DCE • 59  
Default Gateway • 59  
Does the MVI56E-MCM module require processor  
logic? • 58  
Download the Sample Program to the Processor • 9,  
21, 40  
DTE • 59

### E

ESD • 59  
Ethernet • 60

### F

Firmware • 60  
Frequently Asked Questions • 56

Full-Duplex • 60

### G

General Overview • 20

### H

Half-Duplex • 60  
How do I change the module's IP address? • 57  
How do I monitor MVI56E-MCM operation? • 58  
How is the MVI56E-MCM configured? • 57

### I

Import the Ladder Rung • 36  
Important Safety Information - MVI56E and MVI56E-  
XT Modules • 2  
Install ProSoft Discovery Service • 17  
Install the Configuration Tools • 9, 17  
Install the Module in the Rack • 26  
IP Address • 60  
Is the MVI56E product a direct replacement to my  
existing MVI56 product? • 57

### L

Learning Objectives • 9  
LED • 60

### M

MAC ID • 61  
Master • 61  
Memory Map • 23

### N

Network • 61  
Node • 61  
Non-Scrolling LED Status Indicators • 54

### P

Peer-to-Peer • 61  
Physical Setup • 9, 21, 25  
Power Supply • 61  
Prerequisites • 11  
Procedures • 25  
ProSoft Technology Documentation • 10  
ProSoft Technology® Product Documentation • 3  
Protocol • 61

### R

Reboot the Module to Transfer New Parameter Values  
• 21, 46  
Required Items • 14  
Required Steps • 21  
RS-232 • 61

### S

Sample Files • 15  
Scope • 7

Scrolling LED Status Indicators • 53  
Serial Data/Serial Data Transmission • 62  
Server • 62  
Set Module Jumpers • 25  
Set Temporary IP Address • 28  
Set up the Read and Write Database Areas • 41  
Simplex • 62  
Slave • 62  
Subnet Mask • 62  
System Requirements • 13

## **T**

The Sample Application • 9, 19

## **U**

Upload the Add-On Instruction from the Module • 31,  
37

## **V**

Verify Communication • 9, 21, 49  
View Exchanged Data • 49

## **W**

What are the differences between the MVI56 and the  
MVI56E modules? What does the • 56  
What is ProSoft Configuration Builder (PCB)? • 57  
What is ProSoft Discovery Service (PDS)? • 57  
What is the purpose of the MVI56E-MCM Ethernet  
Config (E1) Port? • 57  
What is the purpose of the Optional MVI56E-MCM  
Add-On Instruction? • 58  
What's New? • 8

## **Y**

Your Feedback Please • 4